

ZIP - GRIP

Tripod-Camera Attachment

INSTRUCTIONS:

The ZIP-GRIP adapter disc, which has a beveled rim, screws into the standard tripod socket of your camera. The ZIP-GRIP base, which mounts on the head of your tripod, is equipped with powerful, spring-loaded jaws. The jaws are beveled in the opposite angle to the disc. The disc fits snugly in the jaws of the base. When the lever is moved to CLOSED position, the jaws clamp firmly on the adapter disc, holding it with a vise-like grip. To remove the camera you just flip the lever to OPEN position. The jaws open, and the camera is lifted out.

BROOKS*

BURLEIGH BROOKS OPTICS, Inc.

44 Burlews Court - Hackensack, N.J. 07601

(201) 489-1300 * (212) 279-9085